

ALIEN slim black

category: Kategorie > Piloty programowalne - Programmable remotes HQ Universal



QR code:



Install the batteries in both remote controls and place them on a table with the tip that contains the infrared emitting LED face to face at a distance of 5-7cm. Simultaneously press the first 2 buttons on the top of the Seki remote control, the red Power and CH UP remote control, and hold them for 1 second. Release the buttons, at this point the red LED should flash quickly. Press the key to save. The red light will stay on. Press and hold the desired button on the remote control to copy it and hold it down. The red LED will flash twice long and then quickly again, a sign that the memorization has been made. Repeat the operation for the rest of the buttons you want to save (press the button to be saved, red LED continuously lit, press and hold the save button on the old remote control). When you want to finish saving, press the top 2 buttons simultaneously again. Careful! The remote control goes to store a lot of infrared transmission systems but does not cover 100% of all models. Purchasing for individual use and not for resale, even if small, involves the risk of not fitting your device.